CHAPTER 7

Use & Care Guide

Revised: November 29, 2007, 78-17800-01

Cleaning the Plasma displays

Per industry-standard best practice recommendations for cleaning plasma displays:

The plasma displays require special consideration when cleaning. Wipe the panel surface gently using only a cleaning cloth or a soft, lint-free cloth. If the surface is particularly dirty, wipe with a soft, lint-free cloth which has been soaked in pure water or water to which a small amount of neutral detergent has been added, and then wipe it evenly with a dry cloth of the same type until the surface is dry.

Cleaning the Camera lens

Caution Do not touch the camera after installation is completed. If you need to clean the camera lens, use a dry microfiber cloth. After cleaning, you will need to realign the camera.

Next Steps

- The next chapter,"Field-Replacement and Upgrade Disassembly Instructions", provides instructions on how to remove and replace portions of the Cisco TelePresence System 1000.
- If this installation does not include the purchase of Cisco TelePresence Manager, users should refer to Cisco TelePresence System Administration User's Guide for more information.
- If Cisco TelePresence Manager is included for this installation, the Cisco TelePresence System 1000 administrator should refer to Cisco TelePresence Manager Administrator's Guide to continue the setup of your Cisco TelePresence System 1000.